

VIBRATING WATCH



Charging

1. Pull out of the silicone band to see the USB port.
2. Plug the USB port in your power bank or laptop.
3. A full charge takes about 1 hour (a blue indicator light flashing means in charging, if you don't see it, rotate the USB port and reinsert).
4. A full charge can last 6-20 days, depends on the usage of the watch.
5. Charge in time to save all your settings, the time and countdown timer will be reset when power off but the 15 alarms setting

will be saved by the watch.

6. To check vibration working or not, press any button when the watch is charging.

Setting the Time

1. When screen is black, press **top** button once for time display.
2. Quickly hold down the **top** button until only hours flashing, press top button to increase the hours and below button to decrease the hours.
3. Quickly hold down the **top** button until only minutes flashing, press any button to adjust the minutes.

4. Quickly hold down the **top** button until 12 H or 24 H show, press any button to change the 12/24 hrs setting.

Basic Action

1. Check time: Press top button once
2. Check battery level: Press top button twice (100 is full, reference value)
3. Alarm setting: Press top button 3 times (ALM)
4. Countdown timer setting: Press below button once (Cdn)
5. Top button is for time and 15 alarms setting

6. Below button is for countdown timer setting only
7. Silent Mode: Press any button to turn on the led, quickly press the two buttons **together** for 6 seconds to see "SIL"

Setting up to 15 Alarms

- . Press **top** button 3 times to see ALM, then keep press to cycle through all the 15 alarms (the sequence is ALM, Alarm time 1, A1OF, Alarm time 2, A2OF,... Alarm time 15, 15OF).
- . **To set the alarm time:** press **top** button over and over when alarm time 1 appears, quickly hold down the **top** button until only hours

flashing, press any button to adjust the hours, when the hours are correct, quickly hold down the **top** button until only minutes flashing, press any button to adjust the minutes.

- . **To turn on/off the alarm:** when screen is black, press **top** button over and over to see A1OF, quickly hold down the **top** button to change A1ON / A1OF, OF=OFF (one sec vibration).
- . Continue to press **top** button to cycle through all the next alarms, repeat above to change the times and status of the next alarms.

Setting the Timer

- . **To turn on the timer,** when screen is black, press **below** button over and over to see Cdn, 1, 5, 10, 15, 20, 30, 45, 60, 90, 120, 180 min, when the desired timer length appears(15 or 30), quickly hold down the **below** button until “ON” appears (one sec vibration).
- . Now press the below button to see the remaining time, press again is current time, again is battery level.
- . **To turn off the timer,** when screen is black, press **below** button to see the remaining time, quickly hold down

- the below button for 5 seconds until “OFF” appears (one sec vibration)
- . Tips: **if you want to change the current time after setting the timer, first turn off the timer**

Silent Mode

- . Dismiss the vibration for all the alarms and timers at anytime with one click.
- . Press any button to turn on the led, quickly press the two buttons **together** for 7 seconds to see “SIL”(Silent), press the two buttons **together** for 7 seconds again can switch to “Vib” (Vibration)

Note:

- . The vibration can be stopped immediately by press any button, or it will stop automatically in 30sec.
- . The vibration time for Alarm 1 is 60 seconds, longer than other alarms, we recommend Alarm 1 to be wake up alarm, you can set another two more alarms to support Alarm 1 to be snooze function.
- . The alarms will be automatically repeat every day until it is turned off.
- . When the 15 alarms goes off, silent vibration with time flashing to remind.

- . When the timer goes off, silent vibration with no flashes to remind, totally discreet.